

PRODUCT GUIDE

Proudly supplying the widest range of quality wear parts in Australia.







Wear Parts Specialists

GET AUSTRALIA

Our wear parts suit all earthmoving equipment brands, with specialised designs for specific applications.

We manufacture and distribute:

- Weld in cutting edges
- · Bolt on cutting edges
- Excavator teeth and adaptors
- Arrow head and wear armour
- Bucket shrouds and side cutters
- · Bucket skins and wear strips
- Side cutters and wear shrouds
- · Dozer blades and end bits
- Grader blades, overlays and end bits
- Scarifier shanks, blades and tips
- Ripper boots, shanks and guards
- Scraper edges, adaptors, teeth and routers
- Compactor caps, pedestals and cleaner bars
- · White iron "chocky bars" and wear bars
- QT400/QT450/QT500 plates
- Chrome carbide overlay plate
- Custom wear plates
- · Tungsten coating and hard facing
- New product development











Choc Bar










Our extensive product range includes dozer edge and grader blades, adaptors, scraper edges, bolts, ripper boots, bucket teeth and many more.



Proud distributors of Blackcat Wear Parts.



We stock high-quality wear parts from leading manufacturers committed to product development, innovation and maximising wear life.







CONTACT US

EMAIL INQUIRIES

sales@get.com.au

BRISBANE

62 Neon Street Sumner Park QLD 4074 Ph: +61 7 3376 4477

SYDNEY

6/16 Bernera Road Prestons NSW 2170 Ph: +61 2 9755 3482

MELBOURNE

10 Bolt Court Hallam VIC 3803 Ph: +61 3 9796 4114